





# Interchangeable buttons - TECHNICAL CHARACTERISTICS



2- module push button



2 1-module buttons



1 2-module button



3-module push button



3 1-module buttons



1-module and 2-module buttons

## Interchangeable buttons

### Eikon

For white version: add .B to the basic code.  
For Next version: add .N to the basic code.

2-module push button	3-module push button	1-module buttons			2-module buttons		
<b>Simple push button</b>							
Simple 20520	Simple 20540	Without symbol 20531	To customize* 20531.0	With name-plate 20531.1T	Without symbol 20532	To customize* 20532.0	With name-plate 20532.1T
Simple with actuator 20525	Simple with actuator 20545						
<b>Rocker push button</b>							
Rocker 20521	Rocker 20541	Without symbol 20531.S	With ON/OFF symbols 20531.20	With directional arrows 20531.21	Without symbol 20532.S	To customize* 20532.S0	With ON/OFF symbols 20532.20
Rocker with actuator 20526	Rocker with actuator 20546						
<b>Rocker push button with actuator</b>							
Rocker for rolling shutter 20527	Rocker for rolling shutter 20547	With regulation symbol 20531.22	To customize* 20531.S0	With 2 name-plates 20531.2T	With directional arrows 20532.21		With regulation symbol 20532.22
Rocker for SLAVE dimmer 20528	Rocker for MASTER dimmer 20548						

### Idea

For white version: add .B to the basic code.

2-module push button	3-module push button	1-module buttons			2-module buttons		
<b>Simple push button</b>							
Simple 16960	Simple 16980	Without symbol 16971	With general symbol 16971.10	With name-plate 16971.1T	Without symbol 16972	With general symbol 16972.10	With name-plate 16972.1T
Simple with actuator 16965	Simple with actuator 16985						
<b>Rocker push button</b>							
Rocker 16961	Rocker 16981	Without symbol 16971		With ON/OFF symbols 16971.20	Without symbol 16972		With ON/OFF symbols 16972.20
Rocker with actuator 16966	Rocker with actuator 16986		With directional arrows 16971.21				
<b>Rocker push button with actuator</b>							
Rocker for rolling shutter 16967	Rocker for rolling shutter 16987	With regulation symbol 16971.22		With 2 name-plates 16971.2T	With directional arrows 16972.21		With regulation symbol 16972.22
Rocker for SLAVE dimmer 16968	Rocker for MASTER dimmer 16988						

### Plana

For Silver version: add .SL to the basic code.

2-module push button	3-module push button	1-module buttons			2-module buttons		
<b>Simple push button</b>							
Simple 14520	Simple 14540	Without symbol 14531	With general symbol 14531.10	With name-plate 14531.1T	Without symbol 14532	With general symbol 14532.10	With name-plate 14532.1T
Simple with actuator 14525	Simple with actuator 14545						
<b>Rocker push button</b>							
Rocker 14521	Rocker 14541	Without symbol 14531.S		With directional arrows 14531.21	Without symbol 14532.S		With ON/OFF symbols 14532.20
Rocker with actuator 14526	Rocker with actuator 14546		With ON/OFF symbols 14531.20				
<b>Rocker push button with actuator</b>							
Rocker for rolling shutter 14527	Rocker for rolling shutter 14547	With regulation symbol 14531.22		With 2 name-plates 14531.2T	With directional arrows 14532.21		With regulation symbol 14532.22
Rocker for SLAVE dimmer 14528	Rocker for MASTER dimmer 14548						

\* Customization: See the related standard symbols and wordings: Eikon on page 113; Idea on page 227; Plana on page 335.

## Interchangeable buttons

### Eikon: 1-module button

<b>20531</b>	<b>.B</b>	<b>.N</b>	Without symbol, for simple push button
<b>20531.0</b>	<b>.B</b>	<b>.N</b>	Without symbol, for simple push button, customizable on request
<b>20531.S</b>	<b>.B</b>	<b>.N</b>	Without symbol, for rocker push button
<b>20531.S0</b>	<b>.B</b>	<b>.N</b>	Without symbol, for rocker push button, customizable on request


### EIKON



### Idea: 1-module button

<b>16971</b>	<b>.B</b>	Without symbol, for simple push button
<b>16971.10</b>	<b>.B</b>	With general symbol, for simple push button

### IDEA



### Plana: 1-module button

<b>14531</b>	<b>.SL</b>	Without symbol, for simple push button
<b>14531.S</b>	<b>.SL</b>	Without symbol, for rocker push button
<b>14531.10</b>	<b>.SL</b>	With general symbol, for simple push button

### PLANA



## Interchangeable buttons

### Eikon: 1-module button

20531.20	.B	.N	With ON and OFF symbols, for rocker push button
20531.21	.B	.N	With directional arrows symbols, for rocker push button
20531.22	.B	.N	With regulation symbols, for rocker push button
20531.1T	.B	.N	With name-plate, for simple push button
20531.2T	.B	.N	With 2 name-plates, for rocker push button

### EIKON



### Idea: 1-module button

16971.20	.B	With ON and OFF symbols, for rocker push button
16971.21	.B	With directional arrows symbols, for rocker push button
16971.22	.B	With regulation symbols, for rocker push button
16971.1T	.B	With name-plate, for simple push button
16971.2T	.B	With 2 name-plates, for rocker push button


### IDEA



### Plana: 1-module button

14531.20	.SL	With ON and OFF symbols, for rocker push button
14531.21	.SL	With directional arrows symbols, for rocker push button
14531.22	.SL	With regulation symbols, for rocker push button
14531.1T	.SL	With name-plate, for simple push button
14531.2T	.SL	With 2 name-plates, for rocker push button

### PLANA



## Interchangeable buttons

### Eikon: 2-module button

20532	.B	.N	Without symbol, for simple push button
20532.0	.B	.N	Without symbol, for simple push button, customizable on request
20532.S	.B	.N	Without symbol, for rocker push button
20532.S0	.B	.N	Without symbol, for rocker push button, customizable on request

### EIKON



### Idea: 2-module button

16972	.B		Without symbol, for simple and rocker push button
16972.10	.B		With general symbol, for simple push button


### IDEA



### Plana: 2-module button

14532	.SL		Without symbol, for simple push button
14532.S	.SL		Without symbol, for rocker push button
14532.10	.SL		With general symbol, for simple push button

### PLANA



## Interchangeable buttons

### Eikon: 2-module button

20532.20	.B	.N	With ON and OFF symbols, for rocker push button
20532.21	.B	.N	With arrows symbol, for rocker push button
20532.22	.B	.N	With regulation symbol, for rocker push button
20532.1T	.B	.N	With name-plate, for simple push button

### EIKON



### Idea: 2-module button

16972.20	.B		With ON and OFF symbols, for rocker push button
16972.21	.B		With arrows symbol, for rocker push button
16972.22	.B		With regulation symbol, for rocker push button
16972.1T	.B		With name-plate, for simple push button

### IDEA



### Plana: 2-module button

14532.20	.SL		With ON and OFF symbols, for rocker push button
14532.21	.SL		With arrows symbol, for rocker push button
14532.22	.SL		With regulation symbol, for rocker push button
14532.1T	.SL		With name-plate, for simple push button

### PLANA

